



# Dishwasher

SMV26AX00Q

[en] Information for Use

# Further information and explanations are available online:



## **Table of contents**

1 Safety	. 4	8 Features	20
1.1 General information		8.1 Top basket	
1.2 Intended use		8.2 Bottom basket	
1.4 Safe installation		8.4 Etagere	
1.5 Safe use		8.5 Folding prongs	23
1.6 Damaged appliance		8.6 Knife shelf	23
1.7 Risk to children	. 8	8.7 Basket heights	23
<b>2 Preventing material damage</b> 2.1 Safe installation	<b>10</b> 10	<ul><li>9 Before using for the first time</li><li>9.1 Performing the initial config-</li></ul>	24
2.2 Safe use		uration	24
3 Environmental protection and		10 Water softening system	24
saving energy		10.1 Overview of water hardness	0.4
3.1 Disposing of packaging		settings	24
3.2 Saving energy		tem	25
		10.3 Special salt	25
<b>4 Installation and connection</b> 4.1 Scope of supply		10.4 Switching off water soften-	200
4.2 Installing and connecting the	11	ing system	26
appliance	12	11 Rinse aid system	
4.3 Drainage connection	12	11.1 Rinse aid	26
4.4 Drinking water connection		11.2 Setting the amount of rinse aid	27
4.5 Electrical connection	13	11.3 Switching rinse aid system	
5 Familiarising yourself with		off	27
your appliance		12 Detergent	28
5.1 Appliance		12.1 Suitable detergents	
		12.2 Unsuitable detergents	
6 Programmes	18	12.3 Information on detergents	
7 Additional functions	20	12.4 Adding detergent	29

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

13 Tableware	30
<ul><li>13.1 Damage to glass and tableware</li><li>13.2 Arrange tableware</li></ul>	31 31
13.3 Removing tableware	33
14.1 Switching on the appliance 14.2 Setting a programme 14.3 Setting additional functions 14.4 Setting timer programming 14.5 Starting the programme 14.6 Interrupting programme 14.7 Terminate programme 14.8 Switching off appliance	33 33 33 34 34 34 34
15 Basic settings	<b>35</b> 35
16 Cleaning and servicing	37 37 37 37 37 38 38
<b>17 Troubleshooting</b> 17.1 Clean wastewater pump	<b>40</b> 52
<ul> <li>18 Transportation, storage and disposal</li> <li>18.1 Removing the appliance</li> <li>18.2 Protect appliance from frost</li> <li>18.3 Transporting the appliance</li> <li>18.4 Disposing of old appliance</li> </ul>	<b>52</b> 52 53 53 53
19.1 Product number (E-Nr.) and production number (FD)	<b>5</b> 3
20 Technical specifications	55

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications



# 1 Safety

Observe the following safety instructions.

#### 1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

#### 1.2 Intended use

Only use this appliance:

- For cleaning household tableware.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

## 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

#### 1.4 Safe installation

# **⚠** WARNING – Risk of injury!

Improper installation may cause injury.

▶ When installing and connecting the appliance, follow the instructions in the manual and installation instructions.

#### 

Incorrect installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Always use the supplied power cable for the new appliance.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- When installing the appliance, check that the power cable is not trapped or damaged.

### **⚠** WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer
- ▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

Contact between the appliance and installation lines may lead to a defect in these lines, e.g. gas pipes and power lines. Gas from a corroded gas pipe can ignite. A damaged power line can cause a short circuit.

► Check that there is a distance of at least 5 cm between the appliance and installation lines.

# **⚠** WARNING – Risk of injury!

Hinges move when opening and closing the appliance door and can cause injury.

▶ If built-under or integrable appliances are not in a cavity so that one side is accessible, the hinge area must be covered at the side. Covers are available from Customer Service or specialist outlets.

# **△** WARNING – Risk of tipping!

Improper installation may cause the appliance to tip up.

▶ Only install built-under or integrable appliances under a continuous worktop that is securely connected to adjacent cabinets.

#### 1.5 Safe use

#### 

Failure to comply with safety instructions and directions for use on packagings of detergent and rinse aid products may cause serious harm to health.

► Follow the safety instructions and directions for use on the packagings of detergent and rinse aid products.

## **⚠** WARNING – Risk of explosion!

Adding solvents to the interior of the appliance may cause explosions.

- ► Never add solvents to the interior of the appliance. Highly caustic alkaline or highly acidic cleaning agents in conjunction with aluminium parts in the interior of the appliance may cause explosions.
- ▶ Never use highly caustic alkaline or highly acidic cleaning agents, in particular commercial or industrial products, in conjunction with aluminium parts (e.g. grease filters of extractor hoods or aluminium pans), e.g. for the Machine Care programme.

# **⚠** WARNING – Risk of injury!

Leaving the appliance door open may result in injury.

- ► Only open the appliance door to load or unload tableware in order to prevent accidents, e.g. through tripping.
- ▶ Do not sit or stand on the appliance door when open.

Knives and utensils with sharp points can cause injuries.

Arrange knives and utensils with sharp points in the cutlery basket with the points downwards, on the knife shelf or in the cutlery drawer.

# **⚠** WARNING – Risk of scalding!

If you open the appliance door while the programme is running, hot water may splash out of the appliance.

Open the appliance door carefully if the programme is still running.

#### 

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- Do not use steam- or high-pressure cleaners to clean the appliance.

If the insulation of the power cord is damaged, this is dangerous.

- ▶ Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord.

## 1.6 Damaged appliance

#### 

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never operate an appliance with a cracked or fractured surface.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.

#### en Safety

- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → *Page 53* Incorrect repairs are dangerous.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.

#### 1.7 Risk to children

### 

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material. Children may breathe in or swallow small parts, causing them to suffocate.
- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

Children may become trapped in the appliance and suffocate.

- ► Use the childproof lock if fitted.
- ► Never let children play with or operate the appliance.

### **△** WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

# **△** WARNING – Risk of crushing!

With higher-level appliances, children can become crushed between the appliance door and cabinet doors underneath.

Keep an eye on children when opening and closing the appliance door.

#### **⚠** WARNING – Risk of chemical burns!

Rinse aid and detergent may cause chemical burns to the mouth, throat and eyes.

- ► Keep children away from detergent and rinse aid products.
- ► Keep children away from the appliance when open. The water in the interior of the dishwasher is not drinking water. It may contain residues of detergents and rinse aid.

# **⚠** WARNING – Risk of injury!

Children may get their fingers caught in the slots of the tablet collecting tray and injure themselves.

► Keep children away from the appliance when open.

# 2 Preventing material damage

#### 2.1 Safe installation

#### **ATTENTION!**

Improper installation of the appliance may cause damage.

- ▶ If the dishwasher is installed above or below other domestic appliances, follow the information on installation in combination with a dishwasher in the installation instructions for the individual appliances.
- If there is no information or if the installation instructions do not include the relevant information, contact the manufacturer of these appliances to check that the dishwasher can be installed above or below these appliances.
- If no information is available from the manufacturer, the dishwasher should not be installed above or below such appliances.
- ▶ To ensure the safe operation of all domestic appliances, continue following the installation instructions for the dishwasher.
- Do not install the dishwasher under a hob.
- Do not install the dishwasher near heat sources, e.g. radiators, heat storage tanks, ovens or other appliances that generate heat.

Contact between the appliance and water pipes may lead to corrosion of these pipes, possibly causing them to leak.

 Check that there is a distance of at least 5 cm between the appliance and the water pipe. The pipes supplied for the drinking water and waste water connections are not affected here.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- Make sure that the water pressure in the water supply system is min. 50 kPa (0.5 bar) and max. 1000 kPa (10 bar).
- ▶ If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.

#### 2.2 Safe use

#### **ATTENTION!**

Escaping water vapour can damage fitted units.

- When the programme ends, leave the appliance to cool down for a while before opening the door.
- Special salt for dishwashers can damage the tub due to corrosion.
- To make sure that any special salt that escapes is washed out of the tub, add the special salt to the dispenser for special salt immediately before the programme starts.

Detergent may damage the water softening system.

 Only fill the dispenser of the water softening system with special dishwasher salt.

Unsuitable cleaning agents may damage the appliance.

▶ Do not use a steam cleaner.

- So as not to scratch the finish on the appliance, do not use sponges with a rough surface or abrasive cleaning agents.
- ▶ To prevent corrosion, do not use sponge cloths on dishwashers with a stainless steel front or rinse such cloths thoroughly several times before using them for the first time.

# 3 Environmental protection and saving energy

#### 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

#### 3.2 Saving energy

If you follow these instructions, your appliance will use less electricity and less water

Use the Eco 50 ° programme.

- ✓ The Eco 50 ° programme is energy-efficient and environmentally friendly.
  - → "Programmes", Page 18

If you do not have much tableware to wash, use the additional Half Load function.1

- ✓ The programme will adjust to a lower load and consumption will be reduced.
  - → "Additional functions", Page 20

#### 3.3 Aqua sensor<sup>1</sup>

The agua sensor is an optical measuring device (light barrier) which measures the turbidity of the washing water. You can save water with the agua sensor.

Use of the AquaSensor depends on the programme. If the soiling level is low, the washing water is used in the next wash cycle, allowing water consumption to be reduced by 3-6 litres. If the soiling level is higher, the washing water is drained off and replaced with fresh water. In the automatic programmes the temperature and running time are additionally adjusted to the level of soiling.

## 4 Installation and connection

To ensure proper operation, connect the appliance to the power and water supply correctly. Observe the specified criteria and the installation instructions.

## 4.1 Scope of supply

After unpacking all parts, check for any damage in transit and completeness of the delivery.

If you have any complaints, contact the dealer who sold you the appliance or our Customer Service.

**Note:** The appliance has been tested at the factory to check it is in working order. It is possible that water has left marks on the appliance. These marks will disappear after the first wash cycle.

The delivery consists of the following:

Dishwasher

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

- User manual
- Installation Instructions
- Warranty<sup>1</sup>
- Installation material
- Steam protection<sup>1</sup>
- Rubber apron<sup>1</sup>
- Mains cable
- Quick reference guide<sup>1</sup>

# 4.2 Installing and connecting the appliance

You can position your built-under or integrable appliance in a fitted kitchen between wooden and plastic walls. If you subsequently install your dishwasher as a free-standing appliance, you must stop it from tipping over, e.g. by screwing it to the wall or installing it under a continuous worktop that is securely connected to adjacent cabinets.

- Follow the safety instructions.
   → Page 4
- 2. Follow the instructions for electrical connection. → *Page 13*
- Check the Scope of supply
   → Page 11 and the condition of
  the appliance.
- Consult the installation instructions for the installation dimensions required.
- Make the appliance level using the height-adjustable feet.
   Make sure that the appliance is standing on the floor securely.
- 6. Install the drainage connection.

  → Page 12
- Install the drinking water connection. → Page 12
- **8.** Connect the appliance to the power supply.

## 4.3 Drainage connection

Connect your appliance to drainage connection so dirty water is discharged via the wash cycle.

#### Installing the drainage connection

- Consult the installation instructions supplied for the steps required here.
- 2. Connect the wastewater hose to the outlet connection of the siphon using the enclosed parts.
- When doing so, check that the wastewater hose is not kinked, crushed or twisted.
- 4. Also check that there is no cover in the drainage system preventing the wastewater from being discharged.

# 4.4 Drinking water connection

Connect your appliance to a drinking water connection.

# Installing the drinking water connection

#### Note

- If you are replacing the appliance, you must use a new water supply hose.
- Consult the installation instructions supplied for the steps required here.
- Connect the appliance to the drinking water connection using the enclosed parts.
  - Observe the Technical data → Page 55.
- When doing so, check that the drinking water connection is not kinked, crushed or twisted.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

#### 4.5 Electrical connection

#### Connecting the appliance to the electricity supply


#### **Notes**

- Please follow the Safety instructions  $\rightarrow$  Page 4.
- Connect the appliance to alternating current only, in the range of 220 - 240 V and 50 Hz or 60 Hz.
- Please note that the water safety system is only functional if there is a power supply.
- 1. Insert the non-heating appliance plug of the power cable into the appliance.
- 2. Insert the mains plug of the appliance into a nearby socket.
  - The connection data for the appliance can be found on the rating plate.
- 3. Check that the mains plug is inserted properly.

# 5 Familiarising yourself with your appliance

### 5.1 Appliance

You can find an overview of the parts of your appliance here.



Rating plate with E number and FD num-Rating plate ber  $\rightarrow$  Page 54. The data you need for Customer Service → Page 53.

Depending on the appliance specifications


2	Detergent dispenser	Add detergent to the detergent dispenser.  → "Detergent", Page 28
3	Bottom basket	Bottom basket → Page 21
4	Dispenser for special salt	Add special salt to the dispenser for special salt.  → "Water softening system", Page 24
5	Lower spray arm	The lower spray arm washes the tableware in the bottom basket.  If the tableware has not been washed properly, clean the spray arms.  → "Cleaning spray arms", Page 39
6	Tablet collecting tray	During the wash cycle tablets automatically fall out of the detergent dispenser into the tablet collecting tray where they can fully dissolve.
7	Top basket	Top basket → Page 21
8	Cutlery shelf <sup>1</sup>	Cutlery shelf → Page 22
9	Upper spray arm	The upper spray arm washes the tableware in the top basket.  If the tableware has not been washed properly, clean the spray arms.  → "Cleaning spray arms", Page 39
10	Filter system	Filter system → Page 38
11	Cutlery basket <sup>1</sup>	Cutlery basket → Page 22
12	Dispenser for rinse aid	Add rinse aid to the dispenser for rinse aid.  → "Rinse aid system", Page 26

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

#### 5.2 Controls

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

With some buttons you can perform different functions.



<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

10	Display	The display shows information about the remaining running time or the basic settings. You can change the basic settings via the display and the setting buttons.  → "Changing basic settings", Page 36
----	---------	--

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

## 6 Programmes

You can find an overview of the programmes that can be selected here. Different programmes, which can be found on the control panel of your appliance, are available depending on the appliance configuration. The running time may vary depending on the programme selected. The running time depends on the water temperature, the quantity of tableware, the level of soiling and the Additional function selected. The

runtime will change if the rinse aid system is switched off or rinse aid needs to be added.

The consumption values can be found in the quick reference quide. The consumption values relate to normal conditions and a water hardness of 16 - 20 °E. Different influencing factors such as water temperature or pipe pressure may result in deviations.

Programme	Use	Programme sequence	Additional functions
Intensive 70°	Tableware:  Washing pots and pans, non-fragile tableware and cutlery.  Level of soiling:  Removing stubborn burned or dried-on food remnants containing starch and protein.	Intensive:  Pre-Rinse  Clean 70 °C  Intermediate rinse Final rinse 69 °C  Drying	All → "Additional func- tions", Page 20
	powder detergent, you can also ap- ply a little to the inside of the appli- ance door.		
eco Eco 50°	Tableware:  Cleaning mixed tableware and cutlery. Level of soiling:  Removing common household food remnants lightly dried-on.	Most economical programme:  Pre-Rinse Cleaning 50 °C Intermediate rinse Rinsing 66 °C Drying	All → "Additional func- tions", Page 20

Programme	Use	Programme sequence	Additional functions
Y Glass 40°	Tableware:  Cleaning delicate tableware, cutlery, temperature-sensitive plastics, glasses and stemware in the stemware basket.  Level of soiling:  Removing lightly adhering fresh food remants.	Particularly gentle: Pre-Rinse Cleaning 40 °C Intermediate rinse Final rinse 60 °C Drying	VarioSpeed Half Load ExtraDry → "Additional func- tions", Page 20
©; <b>%</b> Quick 65°	Tableware:  Cleaning mixed tableware and cutlery. Level of soiling:  Removing common household food remnants lightly dried-on.	Time-optimised:  Cleaning 65 °C  Intermediate rinse  Rinsing 70 °C  Drying	ExtraDry → "Additional func- tions", Page 20
<b>»∑</b> © □□ S Quick 45°	Tableware:  Cleaning delicate tableware, cutlery, temperature-sensitive plastics and glasses.  Level of soiling:  Removing lightly adhering fresh food remants.	Time-optimised: Cleaning 45 °C Intermediate rinse Rinsing 55 °C	ExtraDry → "Additional func- tions", Page 20
/∰ PreRinse	Tableware:  Cleaning all types of dishes. Level of soiling: Cold rinsing, intermediate cleaning.	Cold rinse: ■ Pre-Rinse	None

## 7 Additional functions

You can find an overview of the additional functions that can be selected here. Different additional functions, which can be found on the control panel of your appliance, are available depending on the appliance configuration.

Additional function	Use
VarioSpeed	<ul> <li>The running time is shortened by 20% to 50% depending on the washing programme.</li> <li>Energy and water consumption are increased.</li> </ul>
Half Load	<ul> <li>Switch on for small loads.</li> <li>It is recommended that less detergent is added to the detergent dispenser than for a full machine load.</li> <li>The running time is shortened.</li> <li>Energy and water consumption are reduced.</li> </ul>

Additional function	Use
អ្វី <sup>+</sup> Hygiene <sup>+</sup> HygienePlus	<ul> <li>To ensure a higher hygiene status for the appliance and tableware, the temperature is raised and maintained for an extra-long period.</li> <li>Especially suitable for cleaning chopping boards or baby bottles.</li> <li>Continuous use of this function increases the hygiene status.</li> <li>This will increase the running time and energy consumption.</li> </ul>
SytraDry  ExtraDry	<ul> <li>For a better drying result the final rinse temperature is increased and the drying phase extended.</li> <li>Especially suitable for drying plastic parts.</li> <li>There is a slight increase in energy consumption and the running time is extended.</li> </ul>

#### 8 Features

You can find an overview of the possible features of your appliance and how to use them here.

These features depend on the model of your appliance.

#### 8.1 Top basket

Arrange cups, glasses and small items of tableware in the top basket.




Knife shelf a

You can adjust the height of the top basket to make room for larger items of tableware.


#### Adjusting top basket with side levers

To wash large items of tableware in the baskets, adjust the shelf position of the top basket.

- 1. Pull out the top basket.
- 2. To prevent the basket from suddenly dropping down, hold the side of the basket by the top edge.
- 3. Press in the levers on the right and left on the outside of the basket.



4. Raise or lower the basket evenly to the right level.




Check that the basket is level on both sides.

- 5. Release the levers.
- ▼ The basket clicks into position.
- 6. Slide the basket back in.

#### 8.2 Bottom basket


Arrange pans and plates in the bottom basket.



Cutlery basket a<sup>1</sup> Large plates up to a diameter of 31/34 cm<sup>1</sup> can be arranged as shown.


Depending on the appliance specifications

#### en Features




## 8.3 Cutlery basket

Arrange cutlery in the cutlery basket, always without sorting it and with the sharp points downwards.



#### 8.4 Etagere

Use the cutlery shelf and space underneath for small cups and glasses or for large items of cutlery, e.g. cooking spoons or serving cutlery.




If you do not need the cutlery shelf, you can fold it up.

### Adjusting etagere<sup>1</sup>

You can adjust the height of the etagere.

**1.** Position the etagere vertically and pull it upwards ①.




- Position the etagere at a slight angle and move to the right height
   2.
- 3. Push the etagere down.
- ▼ The etagere clicks into position.

Depending on the appliance specifications

## 8.5 Folding prongs

Use the folding prongs to position tableware securely, e.g. plates.




You can fold the prongs down to position pans, bowls and glasses better.

#### Folding down prongs<sup>1</sup>

If you do not need the pronas, fold them down.


1. Push the lever forwards ① and fold down the prongs 2.



- 2. To use the prongs again, fold them back up.
- ▼ The prongs audibly click into posi-

#### 8.6 Knife shelf

Use the shelf for knives and long items of cutlery.



#### 8.7 Basket heights

Set the baskets at the right height.

#### Appliance height 81.5 cm with cutlery basket

Level	Top basket	Bottom basket
1 max. ø	22 cm	30 cm/31 cm → Page 21
2 max. ø	24.5 cm	27.5 cm

Depending on the appliance specifications

Level	Top basket	Bottom basket
3 max. ø	27 cm	25 cm

# 9 Before using for the first time

# 9.1 Performing the initial configuration

On initial start-up or after a reset to the factory settings, you will need to make settings.

**Requirement:** The appliance has been installed and connected.

- → Page 11
- 1. Add special salt.
- 2. Add rinse aid. → Page 26
- 3. Switch on the appliance.
- Setting the water softening system.
   → Page 25
- 5. Set the amount of rinse aid to be dispensed. → Page 27
- 6. Add detergent.

 Start the Programme with the highest cleaning temperature without tableware.

To remove any marks from water or other residues, we recommend you operate the appliance without tableware before using it for the first time.

**Tip:** You can change these settings and other Basic settings at any time.

# 10 Water softening system

Hard water leaves limescale on the tub and tableware and parts of the appliance may become blocked. To ensure good dishwashing results, you can treat the water with special salt and the water softening system. To avoid damage to the appliance, water with a hardness above 9 °E must be softened.

### 10.1 Overview of water hardness settings

You can find an overview of the water hardness values that can be selected here.

You can find out how hard your water is from your local water company or by using a water hardness tester.

Water hardness °E	Hardness range	mmol/l	Setting value
0 - 8	Soft	0 - 1.1	H:00
9 - 10	Soft	1.2 - 1.4	H:01
11 - 12	Medium	1.5 - 1.8	H:02
13 - 15	Medium	1.9 - 2.1	H:03
16 - 20	Medium	2.2 - 2.9	H:04
21 - 26	Hard	3.0 - 3.7	H:05
27 - 38	Hard	3.8 - 5.4	H:06

Water hardness °E	Hardness range	mmol/l	Setting value
39 - 62	Hard	5.5 - 8.9	H:07

**Note:** Set the water hardness determined on your appliance.

→ "Setting water softening system", Page 25

With a water hardness of 0 - 8 °E you can dispense with special salt and switch off the water softening system.

→ "Switching off water softening system", Page 26

# 10.2 Setting water softening system

Set the water hardness on your appliance.

- Determine the water hardness and the appropriate setting value.
   → "Overview of water hardness set-
  - → "Overview of water naraness se tings", Page 24
- 2. Press ①.
- Hold programme button A and press Start repeatedly until the display shows H:xx.
- **4.** Release programme button A and Start.
- Programme button A flashes and the display shows H:04.
- Press programme button C repeatedly until the right water hardness has been set.
- 6. Press Start to save the setting.

#### 10.3 Special salt

You can use special salt to soften water.

#### Adding special salt

If the special salt refill indicator lights up, add special salt to the dispenser for special salt just before the programme starts. The consumption of

special salt depends on the water hardness. The higher the water hardness, the greater the consumption of special salt.

#### **ATTENTION!**

Detergent may damage the water softening system.

 Only fill the dispenser of the water softening system with special dishwasher salt.


Special salt for dishwashers can damage the tub due to corrosion.

- To make sure that any special salt that escapes is washed out of the tub, add the special salt to the dispenser for special salt immediately before the programme starts.
- **1.** Unscrew the lid of the dispenser for special salt and remove.
- 2. On initial start-up: Fill the dispenser right up with water.

**3. Note:** Only use special salt for dishwashers.

Do not use salt tablets. Do not use table salt.

Add the special salt to the dispenser.



#### Funnel a

Fill the dispenser right up with special salt. The water in the dispenser is displaced and forced out.

**4.** Place the lid back on the dispenser and turn to close.

# 10.4 Switching off water softening system

#### Note

To avoid damage to the appliance, only switch off the water softening system in the following cases:

- The water hardness is max. 26 °E and you are using combined detergents with salt replacement substances. According to manufacturers, combined detergents with salt replacement substances can generally only be used up to a water hardness of 26 °E without adding special salt.
- The water hardness is 0 8 °E.
   You do not need to use special salt.

- 1. Press ①.
- Hold programme button A and press Start repeatedly until the display shows H:xx.
- Release programme button A and Start
- Programme button A flashes and the display shows H:04.
- Press programme button C repeatedly until the display shows H:00.
- **5.** Press Start to save the setting.
- The water softening system is switched off and the salt refill indicator is deactivated.

## 11 Rinse aid system

You can use the rinse aid system and rinse aid to get tableware and glasses rinsed perfectly without marks.

#### 11.1 Rinse aid

For optimum drying results, use rinse aid.


Only use rinse aid for domestic dishwashers.

#### Adding rinse aid


If the rinse aid refill indicator lights up, top up with rinse aid. Only use rinse aid for domestic dishwashers.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

1. Press the catch on the lid of the dispenser for rinse aid 1 and lift 2



2. Add rinse aid up to the max mark.



- 3. If rinse aid spills out, remove it from the tub.
  - Spilled rinse aid can cause excessive frothing during the wash cycle.
- 4. Close the lid of the dispenser for rinse aid.
- The lid clicks into position.

#### 11.2 Setting the amount of rinse aid

If there are streaks or water marks on tableware, change the amount of rinse aid.

- 1. Press ①.
- 2. Hold programme button A and press Start repeatedly until the display shows H:xx.

- 3. Release programme button A and Start.
- Programme button A flashes and the display shows H:04.
- 4. Press programme button A repeatedly until the display shows the value set at the factory r:05.
- 5. Press programme button C repeatedly until the right amount of rinse aid has been set.
  - A low setting adds less rinse aid during the wash cycle and reduces streaking on tableware.
  - A higher setting adds more rinse aid during the wash cycle, reduces water marks and improves the drying result.
- **6.** Press Start to save the setting.

#### 11.3 Switching rinse aid system off

If you find the rinse aid refill indicator irritating, e.g. when using combined detergents with a rinse aid component, you can switch the rinse aid system off.

**Tip:** The function of rinse aid is limited with combined detergents. You will generally get better results using rinse aid.

- 1. Press ①.
- 2. Hold programme button A and press Start repeatedly until the display shows H:xx.
- 3. Release programme button A and Start.
- Programme button A flashes and the display shows H:04.
- 4. Press programme button A repeatedly until the display shows the value set at the factory r:05.
- 5. Press programme button C repeatedly until the display shows r:00.

- **6.** Press Start to save the setting.
- The rinse aid system is switched off and the rinse aid refill indicator is deactivated.

# 12 Detergent

#### 12.1 Suitable detergents

Only use detergents that are suitable for dishwashers. Both separate and combined detergents are suitable. For optimum washing and drying results, use separate detergent, adding Special salt and Rinse aid → Page 26 separately.

Modern, powerful detergents mainly use a low-alkaline formulation with enzymes. Enzymes break down starch and remove protein. Oxygen-based bleaching agents are generally used to remove coloured marks, e.g. tea or ketchup.

**Note:** Follow the manufacturer's instructions for each detergent.

Detergent	Description
Tabs	Tabs are suitable for all cleaning functions and do not need to be measured out. With shorter Programmes tabs sometimes do not dissolve entirely and leave residues of detergent. This may impair the cleaning effect.
Powder detergent	Powder detergent is recommended for shorter Programmes. The dosage can be adjusted to the level of soiling.

Detergent	Description
Liquid detergent	Liquid detergent works faster and is recommended for shorter Programmes without PreRinse. Sometimes liquid de- tergent may leak out despite the detergent dispenser being closed. This is not a fault and is non-crit- ical if you remember the following:  Only choose a programme without PreRinse.  Do not select timer program- ming for starting the programme.
	The dosage can be adjusted to the level of soiling.

**Tip:** Suitable detergents are available online via our website or from Customer Service → *Page 53*.

#### Separate detergents

Separate detergents are products that do not contain components other than detergent, e.g. powder detergent or liquid detergent.

With powder and liquid detergent the dosage can be individually adjusted to the level of soiling of the tableware.

For better washing and drying results and to avoid damage to the appliance, please additionally use Special salt and Rinse aid  $\rightarrow$  Page 26.

#### **Combined detergent**

Besides conventional separate detergents, a number of products are available with additional functions. These products contain not only de-

tergent but also rinse aid and salt replacement substances (3in1) and, depending on the combination (4in1, 5in1, ...), additional components such as glass protection or stainless steel cleaner.

According to manufacturers, combined detergents generally only function up to a water hardness of 26 °E. With a water hardness above 26 °E you will need to add special salt and rinse aid. For the best washing and drying results we recommend using special salt and rinse aid from a water hardness of 17 °E. If you are using combined detergent, the washing programme is adjusted automatically to ensure the best possible washing and drying result.

#### 12.2 Unsuitable detergents

Do not use detergent which could cause damage to the appliance or present a risk to health.

Detergent	Description
Hand washing-up liquid	Hand washing-up liquid can cause increased frothing and damage the appliance.
Detergent containing chlorine	Chlorine residue on tableware may present a risk to health.

### 12.3 Information on detergents

Follow the instructions on detergents in everyday use.

■ Detergents marked as "organic" or "ecological" (environmentally friendly) generally contain lower levels of active agents or com-

- pletely dispense with certain substances. The cleaning effect may be restricted here.
- Set the rinse aid and the water softening system to the separate detergent or combined detergent in use.
- According to manufacturers, combined detergents with salt replacement substances can only be used up to a certain water hardness, usually 26 °E, without adding special salt. For the best washing and drying results we recommend using special salt from a water hardness of 17 °E.
- To prevent sticking, only touch detergents in a water-soluble pouch with dry hands and only ever place them in a dry detergent dispenser.
- Even if the rinse aid and special salt refill indicators light up, washing programmes will run properly with combined detergents.
- The function of rinse aid is limited with combined detergents. You will generally get better results using rinse aid.
- Use tablets with a special drying performance.

#### 12.4 Adding detergent

1. To open the detergent dispenser, press the locking latch.

#### en Tableware

2. Add the detergent to the dry detergent dispenser.






If you are using tablets, one is enough. Insert the tablets in a horizontal position.

If you are using powder or liquid detergent, follow the manufacturer's instructions and quantities for dosage in the detergent dispenser.

20 ml – 25 ml detergent is sufficient for normal soiling. If tableware is only lightly soiled, slightly less than the amount of detergent specified is usually sufficient.

**3.** Close the lid of the detergent dispenser.



- The lid clicks into position.
- ✓ The detergent dispenser will open automatically at the optimum time during the programme. Powder or liquid detergent will spread around the washing tank and dissolve there. Tablets will fall into the tablet collecting tray and dissolve in the right dosage. In order to ensure that tablets can dissolve evenly, do not place any other objects in the tablet collecting tray.

**Tip:** If you use powder detergent and select a program with pre-rinse, you can also add a little detergent to the interior door of the appliance.

#### 13 Tableware

Only clean tableware that is suitable for dishwashers.

**Note:** Decorated glassware and parts made of aluminium or silver may fade or discolour with dishwashing. Delicate types of glass may turn cloudy after a few washing cycles.

#### 13.1 Damage to glass and tableware

Only put glasses and china in the dishwasher if it is marked as dishwasher-safe by the manufacturer. Avoid damage to glass and tableware.

Cause	Recommenda- tion
The following tableware is not dishwasher-safe:  Items of cutlery and tableware made from wood  Decorated glassware, antique and hand-crafted tableware  Plastic parts not resistant to heat  Tableware made from copper or tin  Tableware soiled with ash, wax, lubricating grease or paint  Very small items of tableware	Only put tableware in the dishwasher if it is marked as dishwasher-safe by the manufacturer.
The chemical composition of detergent causes damage.	Use a detergent marked by the manufacturer as gentle on tableware.

Cause	Recommenda- tion
Highly caustic al- kaline or highly acidic cleaning solutions, in par- ticular commer- cial or industrial cleaners, are not safe to use in the dishwasher with aluminium.	If you are using highly caustic alkaline or highly acidic cleaning agents, in particular commercial or industrial cleaning agents, do not put aluminium parts in the dishwasher interior.
The water temperature of the programme is too high.	Select a programme with lower temperatures. After the programme has ended, take glassware and cutlery out of the appliance without delay.


## 13.2 Arrange tableware

Arrange tableware correctly to optimise the dishwashing result and prevent damage to both the appliance and tableware.

Load the baskets so that no projecting items of tableware interfere with closing of the door. Projecting items of tableware may push the appliance door open during the programme, so


#### en Tableware

allowing steam to escape and water to leak out around the door. This could damage your kitchen units.



#### **Tips**

- Using the appliance allows you to save energy and water compared to washing-up by hand.
- See our website for examples of how to load your appliance efficiently.
- To save energy and water, load the machine with the number of place settings specified (standard load with tableware and cutlery). → "Technical specifications", Page 55
- For better washing and drying results, position items with curves or recesses at an angle so water can run off.



**1.** Remove large remnants of food from tableware.

To save resources, do not prerinse tableware under running water.

- 2. Observe the following when arranging tableware:
  - Put heavily soiled tableware in the bottom basket, e.g. pans.
     The more powerful the spray jet, the better the dishwashing result will be.
  - To prevent damage to tableware, arrange it so it is stable and cannot tip over.
  - To prevent injury, arrange cutlery with the points and sharp edges facing down.
  - Position containers with the openings facing down so no water can collect in them.
  - Do not block the spray arms make sure that they can turn freely.
  - Do not place small parts in the tablet collecting tray and do not block it with tableware so as not to obstruct the lid of the detergent dispenser.





## 13.3 Removing tableware

## **⚠** WARNING Risk of injury!

Hot tableware can cause burns to the skin. When hot, tableware is sensitive to shock, may crack and can result in injury.

- ▶ When the programme has ended, do not empty the appliance until the tableware has cooled down for a while
- 1. To prevent water dripping on the tableware, unload it starting at the bottom and working up.
- 2. Check the washing tank and accessories for soiling and clean if necessary.
  - → "Cleaning and servicing", Page 37

## 14 Basic operation

#### 14.1 Switching on the appliance

► Press ①.

The Eco 50° programme is set by default.

If you do not perform any actions on the appliance for 15 minutes. the appliance will automatically switch off.1

#### 14.2 Setting a programme

To adjust the washing programme to the soiling level of the tableware, select a suitable programme.

- Press the right programme button. → "Programmes", Page 18
- ✓ The programme is set and the programme button flashes.

#### 14.3 Setting additional functions

You can set additional functions to complete the washing programme selected.

**Note:** The additional functions which can be used depend on the programme selected.

- → "Programmes", Page 18
- Press the button for the relevant additional function.
  - → "Additional functions", Page 20
- ▼ The additional function is set and. the additional function button flashes

#### 14.4 Setting timer programming

You can delay the start of the programme by up to 24 hours.

- 1. Press +.
- ✓ "h:01" appears in the display.
- **2.** Use or + to set the required start time for the programme.
- 3. Press Start.
- This activates timer programming.

Tip: To deactivate timer programming, press — or + repeatedly until "h:00" appears in the display.

### 14.5 Starting the programme

- Press Start.
- ✓ The programme has ended when the display shows "0:00".

Depending on the appliance specifications

#### **Notes**

- If you want to add more tableware while the appliance is running, do not use the tablet collecting tray as a handle for the top basket. You might touch the partially dissolved tablet.
- You can only change a programme when running if you cancel it.
  - → "Terminate programme", Page 34
- The appliance switches off automatically 1 minute after the end of the programme to save energy. If you open the appliance door immediately after the programme has ended, the appliance will switch off after 4 seconds.

#### 14.6 Interrupting programme

**Note:** When you open the appliance door once the appliance has heated up, leave the door slightly ajar for a few minutes and then close it. This will help prevent excess pressure building up in the appliance and stop the appliance door bursting open.

- 1. Open the appliance door carefully.
- 2. Press ().
- The programme is saved and the appliance switches off.
- **3.** Press ① to resume the programme.
- 4. Close the appliance door.

### 14.7 Terminate programme

To end a programme early or to switch from a programme that has already started, you will need to cancel it first.

- 1. Open the appliance door.
- Press Reset 3 sec. for approx. 3 seconds.

- 3. Close the appliance door.
- → The programme is cancelled and ends after approx. 1 minute.

### 14.8 Switching off appliance

- Please note the information on Safe use → Page 10.
- 2. Press ①.
- To prevent damage from dripping water, turn the water tap off tight (not applicable to appliances with Aqua-Stop).

**Tip:** If you press ① during the wash cycle, the programme currently running will be interrupted. When you switch the appliance back on, the programme continues automatically.

# 15 Basic settings

You can configure the basic settings for your appliance to meet your needs.

#### 15.1 Overview of basic settings

The basic settings depend on the features of your appliance.

Basic setting	Display text	Selection	Description	
Water hardness	H:04 <sup>1</sup>	H:00 - H:07	Set the water softening system to your water hardness.  → "Setting water softening system", Page 25 Level H:00 switches the water softening system off.	
Rinse aid dispensing	r:05 <sup>1</sup>	r:00 - r:06	Set the amount of rinse aid to be dispensed.  → "Setting the amount of rinse aid", Page 27 Switch the rinse aid system off with level r:00.	
Intensive drying	d:00 <sup>1</sup>	d:00 - d:01	The temperature is increased during the final rinse, which improves the drying result. This may increase the run time slightly.  Note: Not suitable for delicate items of tableware.  Switch Extra Dry on "d:01" or off "d:00".	
Hot water	A:00 <sup>1</sup>	A:00 - A:01	Set cold water or hot water connection. Only set the appliance to hot water if this can be prepared with little energy and a suitable installation is available, e.g. solar heating system with circulation line. The water temperature should be at least 40 °C and max. 60 °C.  Switch hot water on "A:01" or off "A:00".	
<sup>1</sup> Factory setting	<sup>1</sup> Factory setting (may vary according to model)			

Basic setting	Display text		Description	
TimeLight	S:01 <sup>1</sup>	S:00 - S:02	Switch TimeLight on or off. While the programme is running, status information is projected onto the floor below the appliance door relating to timer programming, the programme or the time remaining. If the base panel is pulled forwards or if the appliance is installed at eye level with the cabinet front fitted flush, the display is not visible.  Level "S:00" switches TimeLight off.	
InfoLight	l:01 <sup>1</sup>	I:00 - I:01	Switch InfoLight on or off. While the programme is running, a spot of light is projected onto the floor below the appliance door. This light will not be visible if the appliance is installed at eye level with the cabinet front fitted flush. If the appliance door is not completely closed, the spot of light will flash. The programme has ended when the spot of light is no longer visible on the floor. Level "I:00" switches InfoLightoff.	
Tone volume	b:02 <sup>1</sup>	b:00 - b:03	Adjustment of tone volume. End of programme indicated by an audible signal tone. Level "b:00" switches the signal tone off.	
<sup>1</sup> Factory setting	<sup>1</sup> Factory setting (may vary according to model)			

## 15.2 Changing basic settings

- 1. Open the appliance door.
- 2. Press ①.
- **3.** Hold programme button A and press Start repeatedly until the display shows H:xx.
- **4.** Release programme button A and Start.
- → Programme button A flashes and the display shows H:04.
- **5.** Press programme button A repeatedly until the display shows the required setting.

**6.** Press programme button C repeatedly until the display shows the right value.

You can change several settings.

- **7.** Press Start to save the setting.
- 8. Close the appliance door.

## 16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

## 16.1 Cleaning the tub

## ⚠ WARNING Risk of harm to health!

Using detergents containing chlorine may result in harm to health.

- Never use detergents containing chlorine
- 1. Remove any coarse soiling in the interior with a damp cloth.
- 2. Add detergent to the detergent dispenser.
- 3. Select the programme with the highest temperature.
  - → "Programmes", Page 18
- 4. Start the programme without tableware. → Page 33

## 16.2 Self-cleaning interior<sup>1</sup>

To remove deposits, the appliance self-cleans the interior at regular intervals.

The programme sequence is automatically adjusted for self-cleaning, e.g. the cleaning temperature is briefly increased. Consumption values, e.g. water and electricity, may also increase.

If the interior is no longer self-cleaned adequately and deposits occur, see this information:

→ "Cleaning the tub", Page 37.

## 16.3 Cleaning products

Only use suitable cleaning products to clean your appliance.

→ "Safe use", Page 10

## 16.4 Tips on appliance care


Follow the tips on appliance care to make sure your appliance functions properly at all times.

Action	Benefit	
Wipe the door seals, the front of the dishwasher and the control panel regularly using a damp cloth and wash- ing-up liquid.	This ensures the parts of the appliance will remain clean and hygienic.	
If the appliance is not going to be used for a while, leave the door slightly ajar.	This will prevent unpleasant odours.	

Depending on the appliance specifications

## 16.5 Filter system

The filter system removes coarse soiling from the dishwashing cycle.




- Micro filter
- 7 Fine filter
- 3 Coarse filter


#### **Cleaning filters**

Soiling in the dishwashing water may block the filters.


- 1. After each wash check the filters for residue.
- 2. Turn the coarse filter anticlockwise ① and remove the filter system ②.
  - Check that no foreign objects fall into the sump.



Pull down the micro filter to remove.




Press the locking catches ① together and lift the coarse filter out ②.



- 5. Clean the filter elements under running water.
  - Carefully clean the rim of dirt between the coarse and the fine filter.
- Re-assemble the filter system.
   Make sure that the locking catches on the coarse filter click into position.


- 7. Insert the filter system into the appliance and turn the coarse filter clockwise.
  - Make sure that the arrow markings match up.




## 16.6 Cleaning spray arms

Limescale and soiling in the dishwashing water may block the nozzles and bearings on the spray arms. Clean the spray arms regularly.

1. Unscrew the upper spray arm ① and pull down to remove 2.



2. Pull up the lower spray arm to remove.



- 3. Check the outlet nozzles on the spray arms for blockages under running water and remove any foreign bodies.
- 4. Insert the lower spray arm.
- ✓ The spray arm clicks into position.
- 5. Insert the upper spray arm and screw it firmly in place.

## 17 Troubleshooting

## **⚠** WARNING

#### Risk of electric shock!

Improper repairs are dangerous.

- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.


Fault	Cause and troubleshooting
E:12 lights up.	<ul> <li>Appliance has detected calcified heating element.</li> <li>Descale the appliance.</li> <li>Operate the appliance with the water softening system.<sup>1</sup></li> </ul>
E:14 lights up.	<ul> <li>Water protection system is activated.</li> <li>1. Turn off the water tap.</li> <li>2 Call Customer Service → Page 53.</li> </ul>
E:15 lights up.	<ul> <li>Water protection system is activated.</li> <li>1. Turn off the water tap.</li> <li>2 Call Customer Service → Page 53.</li> </ul>
E:16 lights up.	<ul> <li>Water is continuously running into the appliance.</li> <li>1. Turn off the water tap.</li> <li>2 Call Customer Service → Page 53.</li> </ul>
E:18 or indicator for water supply lights up.	Supply hose is kinked.  Install the supply hose without kinks.
	Water tap is turned off.  ► Turn on the water tap.
	Water tap is jammed or furred up.  ► Turn on the water tap.
	The flow rate must be at least 10 I/min when the water supply is open.
	The filters in the water connection of the supply or AquaStop hose are blocked.  1. Switch off the appliance.  2. Pull out the mains plug.  3. Turn off the water tap.  4. Unscrew the water connection.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

#### Fault

#### Cause and troubleshooting

E:18 or indicator for water supply lights up. 5. Remove the filter from the supply hose



- 6. Clean the filter.
- **7.** Re-insert the filter in the supply hose.
- 8. Screw the water connection back on.
- Check the water connection for leaks.
- 10. Restore the power supply.
- 11. Switch the appliance on.

E:22 lights up.1

Filters are soiled or blocked.

- Clean the filters.
  - → "Cleaning filters", Page 38

E:24 lights up. Water is not drained.

Not an appliance fault. Siphon connection is still closed or the wastewater hose is kinked or blocked.

- 1. Check the connection to the siphon and open if necessary.
- Install wastewater hose without kinks.
- Remove residues.



Not an appliance fault. Wastewater pump is blocked or the cover of the wastewater pump is loose.

- 1. Clean the wastewater pump.
  - → "Clean wastewater pump", Page 52
- 2. Secure the cover of the wastewater pump so it clicks into position.
  - → "Clean wastewater pump", Page 52

Depending on the appliance specifications

Fault	Cause and troubleshooting
E:24 lights up. Water is not drained.	
E:25 lights up.	Not an appliance fault. Wastewater pump is blocked or the cover of the wastewater pump is loose.  1. Clean the wastewater pump.  → "Clean wastewater pump", Page 52  2. Secure the cover of the wastewater pump so it clicks into position.  → "Clean wastewater pump", Page 52
E:27 lights up.	<ul><li>Mains voltage is too low.</li><li>This is not a fault on the appliance.</li><li>1. Contact an electrician.</li><li>2. Have the mains voltage and electrical installation checked by an electrician.</li></ul>
Another error code appears on the display. E:01 to E:30	<ol> <li>A technical fault is present.</li> <li>Press ①.</li> <li>Unplug the appliance or switch off the fuse.</li> <li>Wait at least 2 minutes.</li> <li>Insert the mains plug of the appliance in a socket or switch on the fuse.</li> <li>Switch the appliance on.</li> <li>If the problem occurs again:         <ul> <li>Press ①.</li> <li>Turn off the water tap.</li> <li>Pull out the mains plug.</li> <li>Contact Customer Service → Page 53 and give the error code.</li> </ul> </li> </ol>
Tableware is not dry.	No rinse aid used or dosage set too low.  1. Add Rinse aid → Page 26.  2. Set the amount of rinse aid to be dispensed.
	Programme or programme option has no drying phase, or the drying phase is too brief.

## Fault Cause and troubleshooting


#### Tableware is not dry.

 Select a programme with drying, e.g. intensive, strong or ECO programme.

Some option buttons decrease the drying result, e.g varioSpeed.

Water collects in recesses of the tableware or cutlery.

Position tableware at an angle where possible.



The combined detergent used has a poor drying performance.

- 1. Use rinse aid to improve drying performance.
- 2 Use a different combined detergent with a better drying performance.

Extra Dry not activated to improve drying performance.

Activate Extra Dry.

Tableware removed too early or drying process not yet ended.

- 1. Wait until the programme ends.
- 2 Only remove tableware 30 minutes after the programme has ended.

Rinse aid used has a limited drying performance.

Use a name-brand rinse aid.
 Eco products may have limited effectiveness.

## Plastic tableware is not dry.

Not a fault. As plastic does not store heat so well, it also does not dry as well.

No remedial action possible.

### Cutlery is not dry.


Cutlery not arranged properly in the cutlery basket or cutlery drawer.

Droplets can form on the cutlery contact points.

- Arrange cutlery individually where possible.
   → Page 31
- **2.** Avoid points of contact.

#### en Troubleshooting

Fault	Cause and troubleshooting
Appliance interior still wet after wash cycle.	Not a fault. The condensation drying principle causes water droplets in the tub – they are indeed desirable here. The moisture in the air condenses on the inside walls, runs off and is pumped out. No action required.
Remnants of food on tableware.	<ul> <li>Tableware is placed too close together or basket is overfilled.</li> <li>1. Arrange tableware with sufficient space in between. The spray jets must reach the surfaces of the tableware.</li> <li>2. Avoid points of contact.</li> </ul>
	<ul><li>Spray arm rotation is blocked.</li><li>Arrange tableware so that it does not obstruct spray arm rotation.</li></ul>
	Spray arm nozzles are blocked.  ► Clean the Spray arms → Page 39.



- Clean the filters.
  - → "Cleaning filters", Page 38



Filters are inserted incorrectly and/or not engaged.

- 1. Insert the filters properly.
  - → "Filter system", Page 38
- 2. Engage the filters.

Washing programme selected too weak.

► Select a more intensive washing programme.

Fault	Cause and troubleshooting
Remnants of food on tableware.	<ul> <li>Tableware has been precleaned too intensely. The sensors chose a weaker programme. Stubborn soiling cannot be entirely removed.</li> <li>Only remove large remnants of food and do not prerinse tableware.</li> </ul>
	<ul> <li>Tall narrow receptacles in corner areas are not rinsed adequately.</li> <li>Do not position tall narrow receptacles at too great an angle or in corner areas.</li> </ul>
	<ul> <li>Top baskets on right and left are not set to same height.</li> <li>▶ Set the upper basket on the left and right to the same height.</li> <li>→ "Top basket", Page 21</li> </ul>
Detergent residue in the appliance	Lid of the detergent dispenser is blocked by items of tableware parts and will not open.  1. Arrange tableware in the top basket tableware so the tab collecting tray is not obstructed by tableware.  → "Arrange tableware", Page 31  Items of tableware are blocking the dispenser lid.  2. Do not place tableware or fragrance dispensers in the tablet collecting tray.
	<ul> <li>The lid of the detergent dispenser is blocked by the tab and will not open.</li> <li>Position the tab in the detergent dispenser crosswise, not vertically.</li> </ul>
	<ul><li>Tabs are used in the quick or short programme. Dissolving time of the tab is not attained.</li><li>▶ Select a more intensive Programme or use Powder detergent.</li></ul>
	Washing effect and dissolving performance are reduced after a prolonged storage time or detergent is very lumpy.  ► Change your detergent → Page 28.

Fault	Cause and troubleshooting
Water marks on plastic parts.	Due to laws of physics droplet formation on plastic surfaces is unavoidable. After drying water marks are visible.
	Select a more intensive programme.
	<ul> <li>Position tableware at an angle.</li> <li>→ "Arrange tableware", Page 31</li> </ul>
	► Use rinse aid.  → "Rinse aid", Page 26
	Set the water softening system higher.
Wipeable or water-sol- uble coatings are present inside the ap-	Detergent substances are deposited there. These coatings cannot generally be removed with chemicals.  • Change your detergent.
pliance or on the door.	► Clean the appliance mechanically.
0001.	<ul><li>White coating is deposited in the appliance interior.</li><li>1. Set the water softening system correctly.</li><li>In most cases you will need to increase the setting.</li><li>2. Change your detergent if required.</li></ul>
	Special salt dispenser is not screwed tight.  Screw the special salt dispenser tight.
Stubborn white coatings are present on tableware, inside the appliance or the door.	Detergent substances are deposited there. These coatings cannot generally be removed with chemicals.  Change your detergent.  Clean the appliance mechanically.
	<ul> <li>Hardness range is set incorrectly or the water hardness is too high.</li> <li>▶ Set the Water softening system → Page 24 to the water hardness or add special salt.</li> </ul>
	<ul> <li>3in1/organic/eco detergent is not effective enough.</li> <li>▶ Set the Water softening system → Page 24 to the water hardness and use separate detergents (proprietary detergent, special salt, rinse aid).</li> </ul>
	Too little detergent is being used.  ► Increase the amount of detergent used or change Detergent.
	Washing programme selected too weak.  ► Select a more intensive washing programme.
Tea residue or lipstick marks on tableware.	Washing temperature is too low.  ➤ Select a programme with a higher washing temperature.
	Too little detergent is being used or is unsuitable.

Fault	Cause and troubleshooting
Tea residue or lipstick marks on tableware.	<ul> <li>Use a suitable Detergent and follow the manufacturer's instructions for the amount to be used.</li> </ul>
	Tableware has been precleaned too intensely. The sensors chose a weaker programme. Stubborn soiling cannot be entirely removed.  ▶ Only remove large remnants of food and do not prerinse tableware.
Coloured coatings (blue, yellow, brown) that are difficult or im- possible to remove are present inside the	The formation of films is due to substances contained in vegetables (cabbage, celery, potatoes, noodles, etc.) or tap water (manganese).  • Clean the appliance.
appliance or on stainless steel tableware.	You can remove deposits with Mechanical cleaning → Page 37 or a machine cleaning product. It may not always be possible to completely remove deposits but they are harmless to health.
	The formation of films is due to metal components on silver or aluminium tableware.  • Clean the appliance.
	You can remove deposits with Mechanical cleaning → Page 37 or a machine cleaning product. It may not always be possible to completely remove deposits but they are harmless to health.
Coloured deposits (yellow, orange, brown) that are easy to remove are present inside the appliance (mainly at the bottom).	<ul> <li>The formation of films is due to ingredients of food remnants and tap water (limescale) "soaplike".</li> <li>1. Check the setting of the water softening system.</li> <li>2. Add special salt.</li> <li>3. If you are using combined detergents (tabs), activate the water softening system.</li> </ul>
	Follow the information on detergents.  → "Information on detergents", Page 29
Plastic parts inside the appliance are discoloured.	Plastic parts inside the appliance may become discoloured during the life of the dishwasher.  Discolouration can come about and will not impair functioning of the appliance.
Plastic parts are discoloured.	Washing temperature is too low.  ► Select a programme with a higher washing temperature.
	Tableware has been precleaned too intensely. The sensors chose a weaker programme. Stubborn soiling cannot be entirely removed.

 Only remove large remnants of food and do not prerinse tableware.

Fault	Cause and troubleshooting
Removable streaks are present on	Amount of rinse aid to be dispensed is set too high.  ▶ Set the rinse aid system to a lower setting.
glasses, glassware with a metallic appearance and cutlery.	No rinse aid has been added.  ► Add rinse aid.  → "Adding rinse aid", Page 26
	Detergent residue is present in the final rinse. Lid of the detergent dispenser is blocked by tableware items and will not open fully.  1. Arrange tableware in the top basket tableware so the tab collecting tray is not obstructed by tableware.
	→ "Arrange tableware", Page 31
	<ul><li>Items of tableware are blocking the dispenser lid.</li><li>Do not place tableware or fragrance dispensers in the tablet collecting tray.</li></ul>
	<ul> <li>Tableware has been precleaned too intensely. The sensors chose a weaker programme. Stubborn soiling cannot be entirely removed.</li> <li>▶ Only remove large remnants of food and do not prerinse tableware.</li> </ul>
Irreversible clouding of glassware.	Glasses are not dishwasher-proof, only suitable for dishwashers.  ► Use dishwasher-proof glasses. Glasses are usually only suitable for use in a dishwasher, i.e. long-term wear or long-term changes must be expected.  ► Avoid a lengthy steam phase (standing time after wash cycle ends).  ► Use a programme with a lower temperature.  ► Set the softening system to the water hardness.  ► Use detergent with a glass protection component.
Rust spots on cutlery.	Cutlery is not sufficiently rust-resistant. Knife blades are often more severely affected.  • Use rust-resistant tableware.
	Cutlery may also rust if washed together with rusting items.  • Do not wash rusting items.
	Salt content in washing water is too high.  1. Remove any spilled special salt from the tub.  2. Screw the cap of the special salt dispenser on tight.

Fault	Cause and troubleshooting
Detergent residue is present in the detergent dispenser or the tablet collecting tray.	<ul> <li>Spray arms were blocked by tableware so detergent was not rinsed out.</li> <li>Check that the spray arms are not blocked and can rotate freely.</li> </ul>
	<ul><li>Detergent dispenser was damp when detergent was added.</li><li>Only add detergent to a detergent dispenser when dry.</li></ul>
Excessive formation of foam occurs.	Hand washing-up liquid is present in dispenser for rinse aid.  ► Immediately add rinse aid to the dispenser.  → "Adding rinse aid", Page 26
	Rinse aid has been spilled.  • Remove the rinse aid with a cloth.
	Detergent or appliance care product used causes excessive foaming.  • Change the brand of detergent.
Special salt refill indicator lights up.	Insufficient special salt. ► Add Special salt.
	Sensor does not detect special salt tablets.  Do not use special salt tablets.
Refill indicator for special salt does not light up.	Water softening system is switched off.  ▶ Set the water softening system.
Refill indicator for rinse aid lights up.	Insufficient rinse aid.  1. Add Rinse aid → Page 26.  2. Set the amount of rinse aid to be dispensed.
Refill indicator for rinse aid does not light up.	Rinse aid system is switched off.  Set the amount of rinse aid to be dispensed.
Display flashes.	<ul> <li>Appliance door is not closed properly.</li> <li>Close the appliance door.</li> <li>Arrange the tableware so that no parts project beyond the basket and prevent the appliance door from closing properly.</li> </ul>
Water is left in the appliance at the end of the programme.	<ul> <li>Filter system or area under the filters is blocked.</li> <li>1. Clean the Filters → Page 38.</li> <li>2. Clean the Wastewater pump → Page 52.</li> </ul>
	Programme has not yet ended.

## en Troubleshooting

Faula	Occupation of two while a bootings
Water is left in the appliance at the end of the programme.	<ul> <li>Cause and troubleshooting</li> <li>Wait until the programme ends or cancel the programme with Reset.</li> <li>→ "Terminate programme", Page 34</li> </ul>
Appliance cannot be switched on or operated.	Appliance functions have failed.  1. Pull out the mains plug or switch off the fuse.  2. Wait at least 2 minutes.  3. Connect the appliance to the power supply.  4. Switch the appliance on.
Appliance does not start.	The mains fuse has tripped.  ► Check the relevant fuse.
	<ul><li>Mains cable is not inserted.</li><li>1. Check whether the socket works.</li><li>2. Check whether the mains cable is properly inserted in the socket and on the rear of the appliance.</li></ul>
	Appliance door is not closed properly.  ► Close the appliance door.
Programme starts automatically.	You did not wait until programme ended.  ► → "Terminate programme", Page 34
Appliance stops during the programme or	Appliance door is not closed properly.  Close the appliance door.
cuts out.	Power and/or water supply has been interrupted.  1. Check the power supply.  2. Check the water supply.
	<ul> <li>Top basket is pressing against inner door and preventing appliance door from being closed securely.</li> <li>Check whether the rear panel of the appliance is being pressed in by a socket or hose holder that has not been removed.</li> <li>Arrange the tableware so that no parts project beyond the basket and prevent the appliance door from closing properly.</li> </ul>

	Troubleshooting en
Fault	Cause and troubleshooting
Appliance door cannot be closed.	<ul> <li>Door lock has been activated.</li> <li>1. Close the appliance door with greater force.</li> <li>2. If the installation conditions prevent quick realignment of the closing system, you can move the door lock back to the home position using a spoon.</li> <li>See the animation for how to move the door lock to the home position.</li> </ul>
	Door cannot be closed due to installation method.  Check whether the appliance has been installed properly.
	When closed, the appliance door, its decor or attached parts should not knock against adjacent cabinets or the worktop.
Lid on the detergent dispenser cannot be closed.	Detergent dispenser or lid are blocked by sticky detergent residue.  Remove detergent residue.
Filling valves making knocking noises.	Caused by the domestic installation. No appliance fault present. Does not affect functioning of the appliance.  • Can only be remedied in the domestic installation.
Knocking or rattling noise.	Spray arm is striking tableware.  • Arrange tableware so that the spray arms do not strike tableware.
	With a small load the water jets directly strike against the tub.

► Distribute the tableware evenly.

cycle.

► Load the appliance with more tableware.

► Position light items of tableware securely.

Light items of tableware move about during the wash


## 17.1 Clean wastewater pump

Large remnants of food or foreign bodies can block the waste water pump. As soon as the rinsing water no longer drains properly, the waste water pump must be cleaned.

## ⚠ WARNING Risk of injury!


Sharp and pointed objects or fragments of glass may block the waste water pump and cause injury.

- ► Remove any foreign bodies carefully.
- 1. Disconnect the appliance from the power supply.
- 2. Remove the top and bottom bas-
- **3.** Remove the filter system.
- 4. Scoop out any water. Use a sponge if necessary.
- 5. Prise off the pump cover using a spoon and grip it by the crosspiece.



- 6. Lift the pump cover inwards at an angle and remove.
- You can now reach the impeller with your hand.
- 7. Remove any remnants of food and foreign bodies in the area of the impeller.

8. Insert the pump cover ① and press down 2.



- ▼ The pump cover clicks into posi-
- 9. Install the filter system.
- 10. Insert the top and bottom basket.

## 18 Transportation, storage and disposal

## 18.1 Removing the appliance

- 1. Disconnect the appliance from the mains power supply.
- 2. Turn off the water tap.
- 3. Detach the drainage connection.
- 4. Detach the drinking water connection
- 5. Loosen any screws fastening the appliance to cabinet parts.
- **6.** Remove the base panel if fitted.
- **7.** Pull the appliance out carefully, along with the hose behind it.

## 18.2 Protect appliance from frost

If there is a risk of frost where the appliance will be standing, e.g. in a holiday home, empty the appliance completely.

Empty the appliance. → "Transporting the appliance". Page 53

### 18.3 Transporting the appliance

To avoid damage to the appliance, empty it before transporting.

**Note:** Always transport the appliance upright to prevent residual water getting into the machine's controls and damaging the appliance.

- 1. Remove tableware from the appliance.
- 2. Secure loose parts.
- 3. Turn on the water tap.
- 4. Switch on the appliance.
- **5.** Select the programme with the highest temperature.
  - → "Programmes", Page 18
- 6. Start the programme. → Page 33
- 7. To drain the appliance, terminate the programme after approx. 4 minutes.
  - → "Terminate programme", Page 34
- 8. Switch off the appliance. → Page 34
- 9. Turn off the tap.
- **10.** To empty the residual water out of the appliance, detach the supply hose and let the water drain out.

## 18.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

## **⚠** WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ► With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.

## 19 Customer Service

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (É-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

# 19.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. The rating plate is located inside the appliance door.

→ "Familiarising yourself with your appliance", Page 14

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

## 20 Technical specifications

Weight	Max.: 60 kg
Voltage	220 - 240 V, 50 Hz or 60 Hz
Power rating	2000 - 2400 W
Fuse	10 - 16 A
Water pressure	<ul><li>min. 50 kPa (0.5 bar)</li><li>max. 1000 kPa (10 bar)</li></ul>
Inlet rate	Min. 10 I/min
Water temperature	Cold water: 25 °C
	max. 25°C  MFX SLE9 25°C 10BAR
Capacity	12 place settings



# Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- · Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome** 



## Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

### **BSH Hausgeräte GmbH**

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company

