



ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 11 NW



| | | | |
|--|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |

ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 11 NW

| | | |
|----|--|------------------|
| 1 | Housing | EOMINI.40D-010 |
| 2 | Side Panel | EOMINI.40D-362 |
| 3 | Left Cover | EOMINI.40D-008 |
| 4 | Door Frame | EOMINI.40-369 |
| 8 | Door complete | EOMINI.40-607 |
| 9 | Panel | EOMINI.40D-889 |
| 10 | Connector with 3 poles | E0730733 |
| 21 | Bracket for Thermostat | E050121 |
| 26 | Fixing for Heating Element | E050126 |
| 29 | Green indicator Light,complete | 043828 |
| 30 | Heating Element (Upper and Lower) | CPMINI40-1500WHE |
| 31 | Knob, black-chromed for thermostat | E0ANOT235 |
| 32 | Red indicator Light,complete | E04117R |
| 33 | Thermostat 300°C | OT300.TCSO2 |
| 34 | Refracter Stone(Italian) | CPMINI40-410.410 |
| 35 | Handle with connect part,small | E0BK600.MINI40 |
| 37 | Connector, 2-poles, ceramic for lamp | CRMO57KLMS |
| 38 | Halogen Lamp w.cover glass, square | E015ELCSQ |
| | Halogen Bulb G9 | 06061056 |
| 39 | Lamp On/Off Switch | A040588 |
| 40 | Control Panel Sticker | E015ETKT |
| 49 | Thermostat 300°C | OT300.TCSO2 |
| 50 | Strain Relief PG16 | 010578028 |
| 51 | Electric Connection Cable without plug | E07716422 |

| | | | | |
|--|--|--|--|---|
| | | | |  |
| | | | | |
| | | | | |
| | | | | |