


No.	Name
1	Top Cover
2	Handle Plate
3	Handle Plate
4	Cable
5	Plug
6	Cove Plate
7	Rubber Pad
8	Rubber Pad
9	Cover Selaing Plate
10	Timer Knob
11	Timer
12	Temperature Control
13	Temperature Knob
14	Temperature Dial
15	Switch
16	Indicator Light
17	Waffle Frame
18	Frame
20	Heating Tube
21	Heating Tube Plate
22	Heating Plate
23	Heating Tube Plate
24	Handle



No.	Name
1	Top Cover
2	Handle Plate
3	Handle Plate
4	Cable
5	Plug
6	Cove Plate
7	Rubber Pad
8	Rubber Pad
9	Cover Sealing Plate
10	Timer Knob
11	Timer
12	Temperature Control
13	Temperature Knob
14	Temperature Dial
15	Switch
16	Indicator Light
17	Waffle Frame
18	Frame
20	Heating Tube
21	Heating Tube Plate
22	Heating Plate
23	Heating Tube Plate
24	Handle