



SPARE PART LIST

Spare Part ItemCode	Item name.	PictureId	Price.	Curr.
2865.N20.08000290.4.10	FRONT PANEL FOR 80'S ELECTRICAL COOKER	13		
6260.00058.96	FLUE COVER CAST IRON WITH CERAMIC ENAMEL COATED FOR ALL 700&900	FCT1		
6246.00013.02	HOT PLATE 2,6 Kw 230 V ROUND SHAPE	HR18		
2179.02302.01	COVER LID Ø235x22mm FOR ROUND SHAPE HOT PLATE GALVANISED	HRC1		
6260.00015.45	THERMOPLASTIC KNOB MAIN BODY WITH 6 mm INSERT	KB6		
6260.00015.30	THERMOPLASTIC KNOB SCALE 90-450 C	KBS11		
2179.09028.01	LABEL FOR FRONT PANEL "ÖZT RYAK LER"	LB3		
2179.09028.01B	LABEL SMALL ÖZT RYAK LER-PAINTED	LB3		
6260.00002.05	ADJUSTABLE LEG M6	LG3		
6259.00003.10	CABLE GLAND PG 21	PG21		
6254.00005.01	5 POLE SWITCH FOR 700 SERIES HOT PLATES	SW9		
6248.00016.02	TERMINAL PORCELAIN NO_3	TP1		

